

Temperature Indicator - GM1312 INSTRUCTIONS for Hobbyists

This thermometer can accept up to two Thermocouple inputs, if you only use one, then use Input 1.

1. Remove the back plate and insert the batteries provided.
2. Connect the thermocouple cable noting narrow and wide pins into the reciprocal slots.
3. Press the POWER button to turn on.
4. TYPE K Thermocouple is selected by default, use the "Type" button to select the type of thermocouple you have connected. (See list below)

The instrument will remember the selected type however we recommend you routinely check this each use as it may accidentally get changed or default back when batteries go flat.

You should be set now to just power on/off for normal usage.

CABLE TYPE	COLOUR	MAX TEMP (DEG C)
K	YELLOW	1200
N	ORANGE	1300
R/S	GREEN	1500-1600

